



Eddie Bauer® Smooth Fleece Full-Zip. EB246

PRODUCT MEASUREMENTS

	XS	S	M	L	XL	2XL	3XL	4XL
Body Length at Back	27	28	29	30	31	32	32 1/2	33
Chest Width	18 1/2	20	21 1/2	23	24 1/2	26	28	30
Sleeve	33 3/4	34 1/2	35 1/4	36	36 3/4	37 1/2	38 1/4	39

BODY LENGTH AT BACK

Measured from high point shoulder to finished hem at back.

CHEST WIDTH

Measured across the chest one inch below armhole when laid flat.